


# **Monitor Table Stand**





CAUTION: DO NOT EXCEED RATED LISTED WEIGHT. SERIOUS INJURY OR PROPERTY DAMAGE MAY OCCUR!

AS01T01








# **⚠ WARNING**

- Do not begin the installation until you have read and understood all the instructions and warnings contained in this installation sheet. If you have any questions regarding any of the instructions or warnings, please contact your local distributor.
- This mounting bracket was designed to be installed and utilised ONLY as specified in this manual. Improper installation of this product may cause damage or serious injury.
- Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.
- Always use an assistant or mechanical lifting equipment to safely lift and position the equipment.
- Tighten screws firmly, but do not over tighten. Over tightening can cause damage to the items, This greatly reduces their holding power.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

### **Component Checklist**

**IMPORTANT:** Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, telephone your local distributor for a replacement.



### Package M




### Package P




1++++

### 1. Separating the VESA Plate


# Use Allen key to loosen the screws in order to separate the VESA plate from the adapter bracket assembly. Retain these screws for later use.




### 2. Assembling the Pole to Base




## 3. Installing the Articulated Arm Assembly






5444

### 4. Installing the VESA Plate










Screw the VESA plate onto the display.


Tighten all screws but do not over tighten.

### 5. Installing the Display



Insert the VESA plate onto the mount and use the previously removed screws to secure them. Make sure the display is safely secured before finally releasing.

### 6. Cable Management






Note: Leave slack in the cable for arm movement.

7₩

### 7. Adjustment



Adjust to the desired position or tilt.

- Maintenance
  Check that the bracket is secure and safe to use at regular intervals(at least every three months).
  Please contact your distributor if you have any questions.

9 • ₩ 10