
Floor to Ceiling Cable Display





Fitting Instructions

Make sure the fixings are strong enough to allow tensioning of the cables. Screws supplied are suitable for wooden ceilings for cavity and solid ceilings use the appropriate rawlplugs.

- A) Fix fitting 1 to ceiling
- B) Screw fitting 2 to fitting 1
- C) Use a plumb line to mark the centre position of the floor fitting 5
- D) Adjust the length of cable by loosening the grub screws at 4. cut off the cable in line with point A
- E) Re tighten the grub screws 4
- F) Adjust the tension by screwing 3 into 5. Do not over tighten

Distance between cable centres

The distance between cables depends on the literature or poster holders you are adding. To calculate width required add 34mm to the width of the holder.

EG

A4 poster holder is 210mm wide + 34mm = 244mm

The cable centres need to be 244mm apart

