


ASSEMBLY INSTRUCTIONS

Remove all products from packaging.


1

Attach the threaded bottom part of the post to the base by aligning it with the central hole, pushing through and tightening with the washer and nut provided.



2

To attach your graphic, slide the cross rails(s) through the top and bottom pole pockets on your graphic until central.




Note: If you are using a cross rail at the top and springs at the bottom, there will be a pocket at the top and eyelets at the bottom.

ASSEMBLY INSTRUCTIONS

3

Slot the hooks on the ends of the cross rails into the holes on the top and bottom of the rings on the poles.

Note: If you are using springs at the bottom, simply attach the eyelets to the bottom of the pole with the elastic provided.



ASSEMBLY INSTRUCTIONS

4

Once the main unit is assembled, repeat the process to form a line of café banners.

