
Outdoor Whirlwind

1

4

7





To move the sign when assembled and base filled with water / sand, it is recommended that the frame is titled onto the wheels and pulled / pushed along by holding the top corner of the frame . The handle on the base is not to be used when the base has been filled with water/sand.

Take care not to move the sign over high steps or curbs as damage may be caused to the wheels. Always position the sign on a flat even surface.

Instructions

Disclaimer: We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate