


CONSTANT PRESSURE COUNTER | TABLE VENTO®

INCLUDED



x 1


transport bag




x 1

valve key


ASSEMBLY INSTRUCTIONS




- 1 Remove the product from the cover and place it on a flat, dry surface with the underside facing the floor.



- 2 Unzip the vertical cover lock in the counter/table and find the inflate/deflate valve.




- 3 Unscrew the valve nuts for pumping and prepare the pump. There are 2 valves in the




- 4 Lock the valve by turning the diaphragm needle approximately 90° clockwise with the dedicated key, this prevents air escaping. An unblocked valve will escape air from the product!

counter and table with vertical cover




- 5 Check that the lower cover lock around the underside of the counter/table is fastened. Connect the pump with the dedicated tip to the valve and start inflating with air. There are 2 valves on the counter, the order of pumping does not matter.



- 6 Sufficiently taut fabric will be the signal to finish pumping. Finally, fasten the vertical zipper of the sheathing shown in point 2.


NEEDED



hand pump or electric

CONSTANT PRESSURE COUNTER | TABLE VENTO®

INCLUDED



x 1


transport bag



x 1

velve key

DISASSEMBLY INSTRUCTIONS



- 1 Unfasten the vertical locks of the cover and unscrew the nuts of the inflation valves located inside the counter/table.




- 2 Unlock the valve by turning the diaphragm needle approximately 90° to the left using the key and start pumping out air.

- 3 Fold and pack the product into a dedicated case.

INSTRUCTIONS OF USE

1. Please read the product assembly/disassembly instructions before assembly.
2. When transporting, setting up and assembling the product, take special care to avoid damage to the product or injury during assembly or use.
3. Before disassembling the product, ensure that there are no sharp objects, tools, etc. with sharp edges in the area where the product will be assembled.
4. If using an electric pump, check the condition of the wires before connecting to avoid electric shock.
5. To ensure the safety of users, avoid placing the product in walkways. Improper placement may create a risk of tripping and injury.
6. During rain or snowfall, excess water/snow should be systematically removed from the product.
7. Any soiling should be removed immediately with a damp cloth and warm water without the use of detergents. The use of high-pressure cleaners is prohibited.
8. The product should be cleaned and dry before disassembly. If, due to weather or other circumstances, the product is assembled wet and dirty, it should be disassembled again as soon as possible, dried and cleaned.
9. The product should be stored in a dry and clean place. Translated with DeepL.com (free version)

NEEDED



hand pump or electric



risk of ignition following
contact with a fire or
ignition source



maximum
load up to 100kg